Calibrating Unit New Standard Solution Report

Equipment Location:	Alcotest 7110 STAFFORD 7		Serial No.:	ARSA-0031		
Calibration File No.	01494			: 05/15/2019	Calib. No.:	00034
Certification File No.:			Cert. Date:		Cert. No.:	
Linearity File No.:	01496		Lin. Date:	05/15/2019	Lin. No.:	00029
Solution File No.:	01505		Soln. Date:		Soln. No.:	
Sequential File No.:	01505		File Date:	06/03/2019	Bolli. 110	00210
Sequential Pile 140	01303		The Date.	00/03/2017		
Calibrating Unit: Control Solution %:	WET 0.100%		Model No.:	CU-34		DDUD S3-0014 05/10/2020
Solution Control Lot:	18150				Expires: Bottle No.:	
Solution Control Lot.	10130				boule No.:	0379
Function		Result	Time	Temperature	Com	ment(s)
		%BAC	HH:MM	Simulator (°C)	or E	rror(s)
Ambient Air Blank		0.000%	14:25D			
Control 1 EC		0.099%	14:25D	34.0°C	*** TEST	PASSED ***
Control 1 IR		0.099%	14:25D	34.0°C	*** TEST	PASSED ***
Ambient Air Blank		0.000%	14:26D			
Control 2 EC		0.098%	14:26D	34.0°C	*** TEST	PASSED ***
Control 2 IR		0.099%	14:26D	34.0°C	*** TEST	PASSED ***
Ambient Air Blank		0.000%	14:27D			
Control 3 EC		0.098%	14:28D	34.0°C	*** TEST	PASSED ***
Control 3 IR		0.100%	14:28D	34.0°C	*** TEST	PASSED ***
Ambient Air Blank		0.000%	14:28D			

All tests within acceptable tolerance.

On this date, I installed the above indicated "NEW SOLUTION" in acordance with Alcotest 7110 operator training and procedures established by the (NJSP) Chief Forensic Scientist.

Temperature Probe Serial Number:

Changed By:

Last Name: LUTZ

First Name: DENNIS

MI: J

Signature

7044

Badge No.: 7045 Date: 06/03

06/03/2019

Calibrating Unit New Standard Solution Report

Equipment Location:	Alcotest 7110 STAFFORD		Serial No.:	ARSA-0031		
Calibration File No.:	01494	io wronin i		: 05/15/2019	Calib. No.:	00034
Certification File No.:			Cert. Date:		Cert. No.:	
Linearity File No.:	01496		Lin. Date:	05/15/2019	Lin. No.:	00029
Solution File No.:	01504		Soln. Date:		Soln. No.:	
Sequential File No.:	01504		File Date:	06/03/2019	50111 11011	00213
Calibrating Unit: Control Solution %: Solution Control Lot:	WET 0.100% 18150		Model No.:	CU-34	Serial No.: Expires: Bottle No.:	DDUD S3-0014 05/10/2020 0114
Function		Result	Time	Temperature	Comment(s)	
		%BAC	HH:MM	Simulator (°C)	or E	rror(s)
Ambient Air Blank		0.000%	13:07D			
Control 1 EC		0.088%	13:07D	33.8°C	CONTROL	TEST FAILED
Control 1 IR		0.089%	13:07D	33.8°C	CONTROL	TEST FAILED
Ambient Air Blank		0.000%	13:11D			
Control 2 EC		0.090%	13:12D	33.9°C	CONTROL	TEST FAILED
Control 2 IR		0.092%	13:12D	33.9°C	CONTROL	TEST FAILED
Ambient Air Blank		0.000%	13:13D			
Control 3 EC		0.092%	13:13D	33.9°C	CONTROL	TEST FAILED
Control 3 IR		0.093%	13:13D	33.9°C	CONTROL	TEST FAILED
Ambient Air Blank		0.000%	13:14D			

Test results are not within acceptable range.

On this date, I installed the above indicated "NEW SOLUTION" in acordance with Alcotest 7110 operator training and procedures established by the (NJSP) Chief Forensic Scientist.

Temperature Probe Serial Number:

Changed By:

Last Name: LUTZ

First Name: DENNIS


MI: J

Cianoturo

._/

Badge No.: 7045 Date: 06/03

06/03/2019





State of New Jersey

PHILIP D. MÜRPHY
Gövernor

SHEILA Y. OLIVER L. Governor OFFICE OF THE ATTORNEY GENERAL
DEPARTMENT OF LAW AND PUBLIC SAFETY
DIVISION OF STATE POLICE
POST OFFICE BOX 7068
WEST TRENTON, NJ 08628-0068
(609) 882-2000

GURBIR S. GREWAL
Attorney General

PATRICK J. CALLAHAN

Colonel

CERTIFICATION OF ANALYSIS 0.10 PERCENT BREATH ALCOHOL SIMULATOR SOLUTION

ACCEPTANCE SPECIFICATIONS FOR BREATH ALCOHOL SIMULATOR SOLUTION: Ethyl alcohol concentration within, but not exceeding, the range of 0.1174 to 0.1246 grams per 100 milliliters of solution.

MANUFACTURER: Draeger Safety, Inc.

ANALYSIS DATE: 05/24/2018

BREATH ALCOHOL SIMULATOR SOLUTION LOT NUMBER: 18150

Representative samples of the above-referenced Lot Number were tested by Gas Chromatography and found to have a mean ethyl alcohol concentration range of <u>0.1212</u> to <u>0.1239</u> grams per 100 milliliters of solution.

This lot of breath alcohol simulator solution may be utilized as a known traceable standard for the purpose of conducting periodic tests, pursuant to N.J.A.C. 13:51-4.3, of approved breath test instruments (N.J.A.C. 13:51-3.5) utilized by law enforcement agencies in this State. The manufacturer's expiration date for this lot of breath alcohol simulator solution is May 10, 2020.

As Research Scientist for the Division of State Police, I hereby certify and attest that the tests and results documented in this Certificate of Analysis were performed at the Office of Forensic Sciences of the Division of State Police on properly functioning and calibrated instruments and equipment. All procedures utilized are accurate, objective, and performed on a routine basis by personnel within the Office of Forensic Sciences, in accordance with their professional duties and responsibilities.

Alí M. Alaouie, Ph.D. Research Scientist

NJSP Office of Forensic Sciences

Sworn to and subscribed before me this 29th day of May , 2011

PETER F MURPHY IV My Commission Expires 1 1 August 1, 2019

"An Internationally Accredited Agency"

New Jersey Ix Art Equal Opportunity Employer Printed on Recycled Paper and Recyclable

